

Disassembly Instructions

1. Lift up slightly and pull the securing handle (10) forward. Remove the cover (4).

2. Lift the juice bowl (7) up and off motor base (9) while it still contains the strainer basket (5) and juice ring (6). Then detach these parts.



Parts List

1. Pusher for large opening
2. Pusher for small opening
3. Funnel
4. Cover
5. Strainer basket
6. Juice ring
7. Juice bowl with spout
8. Drive plate
9. Motor base
10. Securing handle
11. Waste pulp receptacle

